

AD-A099 238

HARRY DIAMOND LABS ADELBHI MD
USER'S MANUAL FOR ELECTROMAGNETIC PULSE COUPLING CODE TEMPO. (U)
FEB 81 W J STARK, D A CLARK, R E STRAYER

F/6 20/14

UNCLASSIFIED


HDL-TM-81-2

NL

1 OF 1
40 098258
098258

END
DATE FILMED
6-81
DTIC

AD A 099 238



UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

REPORT DOCUMENTATION PAGE		READ INSTRUCTIONS BEFORE COMPLETING FORM								
1. REPORT NUMBER HDL-TM-81-2	2. GOVT ACCESSION NO. HD-1059-238	3. RECIPIENT'S CATALOG NUMBER								
4. TITLE (and Subtitle) User's Manual for Electromagnetic Pulse Coupling Code TEMPO	5. TYPE OF REPORT & PERIOD COVERED Technical Memorandum									
6. PERFORMING ORG. REPORT NUMBER No	7. AUTHOR(s) Werner J. Stark David A. Clark Roy E. Strayer, Jr.									
8. PERFORMING ORGANIZATION NAME AND ADDRESS Harry Diamond Laboratories 2800 Powder Mill Road Adelphi, MD 20783	10. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS DA: 1L162120AH25 Program Ele: 6.21.20.A									
11. CONTROLLING OFFICE NAME AND ADDRESS U.S. Army Materiel Development and Readiness Command Alexandria, VA 22333	12. REPORT DATE February 1981									
14. MONITORING AGENCY NAME & ADDRESS (if different from Controlling Office)	13. NUMBER OF PAGES 37									
15. SECURITY CLASS. (of this report) UNCLASSIFIED										
16. DISTRIBUTION STATEMENT (of this Report) Approved for public release; distribution unlimited.										
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report)										
18. SUPPLEMENTARY NOTES HDL Project X759E3 DRCMS Code: 612120.H250011										
19. KEY WORDS (Continue on reverse side if necessary and identify by block number)										
<table> <tr> <td>EMP</td> <td>Norton equivalent circuit</td> </tr> <tr> <td>Interactive computer code</td> <td>EMP vulnerability assessment</td> </tr> <tr> <td>Electromagnetic coupling</td> <td>Thevenin equivalent circuit</td> </tr> <tr> <td>Antenna response</td> <td>Electromagnetic pulse</td> </tr> </table>			EMP	Norton equivalent circuit	Interactive computer code	EMP vulnerability assessment	Electromagnetic coupling	Thevenin equivalent circuit	Antenna response	Electromagnetic pulse
EMP	Norton equivalent circuit									
Interactive computer code	EMP vulnerability assessment									
Electromagnetic coupling	Thevenin equivalent circuit									
Antenna response	Electromagnetic pulse									
20. ABSTRACT (Continue on reverse side if necessary and identify by block number)										
<p>A computer code, TEMPO, has been developed to aid in the solution of electromagnetic pulse (EMP) coupling problems. The code is general in nature. It provides approximate solutions to simplified, but practical problems that are commonly encountered during system evaluations. With the aid of TEMPO, an engineer may rapidly determine which sources of coupling are a threat to his system and, consequently, spend more effort on solving those problems than searching for them. This report depicts the organization and the operation of TEMPO on Harry Diamond Laboratories' IBM System/370.</p>										

DD FORM 1 JAN 73 1473 EDITION OF 1 NOV 65 IS OBSOLETE

UNCLASSIFIED


1 SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

1. 7

CONTENTS

	Page
1. INTRODUCTION.....	5
2. CODE ORGANIZATION.....	5
3. DESCRIPTION OF TEMPO PROGRAMS.....	6
3.1 Interactive Programs.....	6
3.1.1 Program INPUT.....	6
3.1.2 Program DRIVE.....	6
3.1.3 Features of Interactive Programs.....	7
3.2 Batch Programs.....	7
3.2.1 Procedure IO.....	7
3.2.2 Program FRQ.....	8
3.2.3 Program ZANT.....	8
3.2.4 Program FIELD.....	8
3.2.5 Program CONVOL.....	8
3.2.6 Program FOURIER.....	8
3.2.7 Program OUTPUT.....	9
4. METHODS FOR EXCHANGING DATA BETWEEN BATCH PROGRAMS.....	9
4.1 Definition of Temporary Data Sets.....	9
4.2 Description of IO Data Cards.....	10
4.3 Definitions for Input-Output Flags.....	10
4.4 Flag Card.....	11
4.5 Definition of ARRAY Parameters (PARAM) 1 to 20.....	17
4.6 Definitions of Field Parameters (FPAR) 1 to 18.....	19
APPENDIX A.—PROCEDURES FOR COMPUTER CODE TEMPO.....	23

DISTRIBUTION.....



FIGURES

	<u>Page</u>
1 Definition of flags IC, ID (mainline—INPUT).....	11
2 Definition of flags IA, IB, IC, IE, IF (CABLE).....	12
3 Definition of flags IA, IE, IF, IN (ANTENNA).....	13
4 Definition of flags IA, IE (APERTURE).....	14
5 Definition of flags IA, IB (DATA).....	14
6 Definition of flags IK, IM, IN (mainline—DRIVE).....	15
7 Definition of flag IL (FUNCTION).....	16
8 Definition of flag IL (SIMULATOR).....	16

1. INTRODUCTION

Most of the presently available codes for computing the solution to an electromagnetic transient problem are written to solve a specific class of problems. If one is interested in solutions to several different types of problems, one must acquire familiarity with a number of different codes. Each code must be examined for its range of validity, and it may have to be modified to fit specific needs. This process may be prohibitively time-consuming, particularly if one is interested in approximate solutions for a wide variety of problems, rather than a very accurate solution to a specialized case. It is the former type of solution, combined with information about the antenna or cable impedance, that often suffices for a vulnerability analysis of a given circuit attached to the antenna or the cable.

The computer code TEMPO was developed with the objective of providing approximate solutions for a wide class of electromagnetic pulse (EMP) interaction problems in a form usable by a circuit analysis code. The application of TEMPO was to be simple and efficient so that the user would require a minimum amount of familiarity with the code, and the code was to be flexible so that a wide variety of solutions could be performed for a number of different conditions. Finally, the problems addressed by TEMPO were to be practical cases that could ultimately be related to commonly occurring problems in an EMP vulnerability assessment.

2. CODE ORGANIZATION

Since TEMPO is used in the EMP vulnerability assessment of complex military systems, it is organized so that its application is an integral part of such an assessment. To do so, the EMP coupling source is represented in terms of either a Thevenin or a Norton equivalent circuit, and a circuit analysis is performed on the equivalent circuit and its load. Since the load circuit usually contains nonlinear elements, the circuit analysis is performed in the time domain by using available network analysis codes for circuits with nonlinear elements.

By separating the EMP vulnerability assessment into two parts consisting of the source equivalent circuit and the load circuit, separate teams of investigators can be assigned to the two types of problems. Initially, the coupling analysis can be performed by using simple linear loads for the equivalent circuit, and the load circuit can be analyzed independently from the coupling source by using simple driving sources. After the coupling source equivalent circuit and the load circuit are adequately modeled, they can be combined for a vulnerability assessment.

Most computer programs using a large scale computer (like the Control Data Corp. (CDC) 6000 series or the IBM System/360 or 370 family of computers) are executed in a batch mode. This mode requires that the user prepare a number of control cards for running the program and data cards for supplying the input parameters to the program. Since the process of preparing such cards can be time-consuming, TEMPO allows for an option to generate the necessary information for running the batch job using two interactive programs. These programs are easily executed at a remote teletypewriter terminal and are designed to aid the user to accurately describe the problem that he wants to solve.

With the interactive portion of initiating the batch job completed, the job can be placed in the batch input queue at the central processing site, and output depends on the normal turnaround

time at the computer center. By running the programs in batch mode, there are no limitations on the size of the programs that can be executed, except for those normally applicable to a batch job. In principle, TEMPO could initiate any pertinent EMP interaction code previously run in a batch mode on a large scale computer.

The result of the computation initiated by TEMPO is normally obtainable in the form of a plot of the transient response. The plot devices can be a remote line printer, a remote x-y bed plotter, or a remote teletypewriter. By using the teletypewriter, it is possible to run TEMPO and obtain an output even if the only remote terminal available to the user is a teletypewriter.

The programs described in this report were written to run on an IBM System/370 Model 168 computer using the time sharing option (TSO)¹ for the interactive portions. They were originally developed to run on a CDC Model 6700 computer using INTERCOM² for the interactive portions. Hence, TEMPO can be run on either system with only a few minor changes from one version to the other.

3. DESCRIPTION OF TEMPO PROGRAMS

3.1 *Interactive Programs*

The present version of TEMPO is written to provide approximate solutions to basic practical coupling problems for interactions with cables, antennas, and apertures. There are many programs and subroutines used for performing the calculations. However, the user need concern himself only with the following two interactive programs for initiating the computation process.

3.1.1 *Program INPUT*

Interactive program INPUT allows the user to select one of five options. Three of the options (ANTENNA, CABLE, and APERTURE) lead to solutions of coupling problems by using theoretical models. The CW (continuous wave) option uses measured frequency-domain data to describe the coupling. The FIELD option does not solve a coupling problem, but allows the user to access program DRIVE without unwanted computations. After specifying a coupling problem, the user is asked to supply information appropriate to that problem. For example, if the choice is ANTENNA, he is asked to describe the antenna, specify the load at the terminal, and add other facts. The user has an option to obtain a brief synopsis of the model used for the computation, including references for additional information on the problem being solved. Once all the parameters for a given problem are defined, the user is asked if he wants output for intermediate steps in the computation. These could be, for example, the frequency spectrum for the transfer function, the impulse response, or the driving field. Finally, he must specify the output medium for any intermediate steps and the transient response for the problem.

3.1.2 *Program DRIVE*

Interactive program DRIVE prompts the user to enter the type of incident field to be used for the problem. Several options for the incident field are available:

¹OSVS2 TSO Command Language Reference, IBM Technical News Letter GC28 0646.3 (July 1976)

²6000 Series INTERCOM 3 Reference Manual, Control Data Corp Publication 60252800, Rev B (January 1972)

- a. A data file, such as an experimentally determined incident field
- b. One of several types of analytic functions (a Gaussian pulse, a sum of two or four exponential curves, a damped sinusoid, a square wave, or a step wave)
- c. A high altitude incident field whose wave shape can have one of the six functional forms in option b
- d. An approximation to the surface burst EMP

Once the choice of the incident field has been made, there is an option to compute the driving field either in the time domain or in the frequency domain. If the incident field is determined from experimental data in the time domain, then there is no choice. However, if the incident field is an analytic function, then computational error generally is minimized by specifying the driving field to be computed in the frequency domain.

3.1.3 Features of *Interactive Programs*

An attempt has been made to anticipate questions that a user might have during an interactive session, and information is provided to the user in response to a HELP command. For example, the user may be asked to specify the type of coupling problem. If he issues a HELP command, the program gives him information on what types of coupling problems can be solved by using TEMPO.

After the interactive session is completed, a batch job is generated. This job can be submitted through TSO to the batch input queue by issuing a SUBMIT'HK3010.JOB.CNTL' command. Alternatively, if a punched deck of the job was requested during the interactive session, this punched deck can be submitted independently of TSO. Once a punched deck for the job has been obtained, this job can be submitted through a card reader at a batch terminal.

3.2 *Batch Programs*

The remaining programs perform the numerical computations and generate an output for the problem specified. They consist of several independent mainline programs and subroutines that pass pertinent data to one another via temporary data sets. Which program is executed depends on the type of problem being solved. For example, the INVERT (inverse Fourier transform) program may or may not be required, depending on whether or not the computations are performed in the time domain. The following sections and appendix A describe the mainline programs and their subroutines.

3.2.1 *Procedure IO*

Although not a FORTRAN program, procedure IO initiates all of the files to be used for inputting, outputting, and transferring data. This procedure creates a file on unit 2 called the IO file and then stores the input-output control (IO) data on the file. The IO file is then read by each program. It both passes pertinent coupling parameters from one program to the next and controls the task of each program. The IO file also stores any measured data submitted with the job.

3.2.2 Program FRQ

Mainline program FRQ reads the IO file, defines the problem to be solved, and calls the appropriate subroutine to compute the frequency spectrum for the response. After the frequency spectrum is computed, the resulting effective height and antenna impedance are written on two separate files for further analysis. Subsequent Fourier transforms are computed for 2048 equispaced frequency points by using the fast Fourier transform (FFT) or for 256 equispaced frequency points by using the LFILON transform.

3.2.3 Program ZANT

Program ZANT computes a lumped parameter network (LPN) equivalent to the antenna impedance for the problem being solved. The program is used if a time-domain equivalent circuit is required to represent the coupling problem. It applies when the antenna impedance shows multiple isolate resonances, so that the antenna impedance is easily represented as a series of parallel resonant circuits.

3.2.4 Program FIELD

Program FIELD computes the incident electric field either in the frequency domain or in the time domain as specified by the user. The subsequent convolution with the impulse response for the problem is performed in the corresponding frequency or time domain. The options available for computing various types of fields have been described in the discussion of interactive program DRIVE.

3.2.5 Program CONVOL

Program CONVOL computes the convolution of two functions, (1) the incident field and (2) the impulse response for current or voltage for a given coupling problem. For a field scattered by an aperture, the second function is the impulse response of the aperture. If both functions are in the frequency domain, the product remains in the frequency domain. If both functions are in the time domain, the convolution integral is performed by using a simple numerical integration in the time domain.

3.2.6 Program FOURIER

Program FOURIER transforms any one of three types of frequency spectra from the frequency domain to the time domain: (1) the effective height of the current or voltage for a given coupling problem or the transfer function for the field scattered by an aperture, (2) the electric field component for the incident or ground-interacted field, or (3) the product of two functions such as the incident field and the effective height of an antenna.

The Fourier transform is performed by using either (1) the Cooley-Tukey³ algorithm for the FFT or (2) a numerical integration combining trapezoidal and Filon techniques (LFILON).⁴ The FFT is used in most cases, and the LFILON transform is available to verify the results obtained by

³J. W. Cooley and J. W. Tukey, *An Algorithm for the Machine Calculation of Complex Fourier Series*, *Mathematics of Computation*, **19** (April 1965).

⁴D. G. Dudley, *Numerical Inversion of the Fourier Transform: A Combination Trapezoidal and Filon Technique*, Lawrence Livermore Laboratories, Livermore, CA, UCRL-51878 (1975).

using the FFT. The FFT is performed by using 2048 equispaced frequency points, whereas the LFILON transform is performed by using 256 points. At present, the frequency points are equispaced for the LFILON transform. However, in general, the LFILON transform can be used with an arbitrary number of points with arbitrary spacings in the time domain, the frequency domain, or both.

3.2.7 Program OUTPUT

Program OUTPUT controls the output processing for a given run. The various selected computed functions are plotted on a bed plotter, a line printer, or a teletypewriter, depending on which device was specified as an output device. The plot routines are described elsewhere for the bed plotter⁵ and for plots on the printer.⁶

4. METHODS FOR EXCHANGING DATA BETWEEN BATCH PROGRAMS

Since TEMPO is a composite of various single purpose programs, the data must be passed from one program to the next. Likewise, the instruction set and the problem parameters must be accessed by each program. The following sections describe the input-output controls, the parameters, and the file allocations.

4.1 Definition of Temporary Data Sets

Tape unit	File name	Type of data
1	-	Temporary data storage used by program OUTPUT
2	IO	Input-output and problem definition parameters
3	FIMP	Frequency-domain impulse response spectrum
4	IMPLS	Time-domain impulse response spectrum
5	FIELD	Time-domain electric field
6	PRINT	Output to printer or teletypewriter
7	SYSOUT=B	Output to bed plotter
8	FFIELD	Frequency-domain electric field
9	FRESP	Frequency-domain response to incident field
10	RESP	Time-domain response to incident field
11	ZA	Antenna and cable impedance

⁵T. V. Noon, Enhanced Plotting Software for Use with the Houston instrument COMPLOT Plotter, Harry Diamond Laboratories HDL-TM-75-32 (December 1975)

⁶Egon Marx, Printer Version of Plots Made by an Incremental Plotter, Harry Diamond Laboratories HDL-TM-75-33 (December 1975)

4.2 Description of IO Data Cards

<u>Card</u>	<u>Label</u>	<u>Description</u>
1	t	Time increment for computing transient wave shape
2	IOFLAG (I), I = 1 to 10	Flags to indicate which type of output and which type of output medium are desired
3	FLAG (I), I = 1 to 20	Flags to describe type of problem to be solved and type of field to be computed; also referred to as FLAG IA, IB, . . . , IR
4 to 7	PARAM (I), I = 1 to 20	Parameters to describe geometry and physics of scattering object
8 to 10	FPAR (I), I = 1 to 18	Parameters to describe incident electric field for problem

4.3 Definitions for Input-Output Flags

<u>Term</u>	<u>Definition</u>
MULCURVE	IOFLG9 =1, 2, . . . , Depending on whether RESP, FIELD, . . . , contain multiple curves
NCURVE	IOFLG10 =Number of curves - 1 that are to be plotted if MULCURVE ≠ 0
FSPEC	IOFLG4 =0 plot magnitude and phase =1 plot real and imaginary

IOFLG(I), I = 1, 2, 3, 5, 6, 7, 8, are the outputs of files RESP, FIELD, IMPLS, FRESP, FFIELD, FIMP, and ZA, respectively, and are plotted in accordance with IOFLG4 and the following:

Linear x and y scales:

- IOFLG(I) =1 plot output on teletypewriter
- =2 plot output on printer
- =3 plot output on plotter

Allowed values for IOFLG(I) I = 1, 2, 3, 5, 6, 7, 8

Linear x scale, log y scale for magnitude, real, imaginary and

Linear x scale, linear y scale for phase:

- IOFLG(I) =5 plot output on printer
- =6 plot output on plotter

Allowed values for IOFLG(I) I = 5, 6, 7, 8

Log x scale, log y scale for magnitude, real, imaginary and

Log x scale, linear y scale for phase:

- IOFLG(I) =8 plot on printer
- =9 plot on plotter

Allowed values for IOFLG(I) I = 5, 6, 7, 8

4.4 Flag Card

The flag card has 20 integers in columns 1 to 20: flags IA to IT. The flags control the routing within the mainline programs and the subroutines so that the desired problem will be solved. Figures 1 to 8 indicate the uses of the flags.




Figure 1. Definition of flags IC, ID (mainline—INPUT).




Figure 2. Definition of flags IA, IB, IC, IE, IF (CABLE).




Figure 3. Definition of flags IA, IE, IF, IN (ANTENNA).




Figure 4. Definition of flags IA, IE (APERTURE).




Figure 5. Definition of flags IA, IB (DATA).




Figure 6. Definition of flags IK, IM, IN (mainline—DRIVE).




Figure 7. Definition of flag IL (FUNCTION)




Figure 8. Definition of flag IL (SIMULATOR)

The following flags are used in addition to those defined in figures 1 to 8.

<u>Flag</u>	<u>Description</u>
IH	Computation of equivalent network for antenna impedance IH = 0 computation not required IH = 1 computation required
IS	Method used for computing Fourier transform IS = 0 use FFT IS = 1 use LFILON transform
IT	Debug option IT = 0 no debug option IT = 1 debug option desired

4.5 Definition of ARRAY Parameters (PARAM) 1 to 20

<u>Parameter</u>	<u>Definition</u>
PARAM(1)	= RHO (resistivity) definition when solving cable problem RHO = -5E-5 if analytical model C1 is used RHO = 1 / SIGMA (SIGMA = ground conductivity) if analytical model C2 is used
PARAM(2)	For cable problem, = R1 of series resistance-inductance-capacitance (RLC) at cable terminals (ohms). For antenna problem, = R of RLC load at antenna feed point (ohms). For continuous wave (cw) problem, = R = load resistance (ohms). For aperture problem, = H = length of aperture (meters).
PARAM(3)	For cable problem, = L1 of series RLC at cable terminals (henries). For antenna problem, = L of RLC load at antenna feed point (henries). For cw problem, = IND= load inductance (henries). For aperture problem, = W = width of aperture (meters)
PARAM(4)	For cable problem, = C1 of series RLC at cable terminals (farads). For antenna problem, = C of RLC load at antenna feed point (farads). For cw problem, = C = load capacitance (farads). For aperture problem, = R = distance from aperture for computing electric field (meters)
PARAM(5)	For cable problem, = R2 of series RLC at cable terminals (ohms). For antenna problem, = H = length of antenna for monopole and dipole antennas (meters) = B = loop radius for loop antennas (meters) = H = missile length for missile problems (meters) = H1 = 0.3 for AS1852 antenna, = 0.35 for AS1852 antenna (meters)

<u>Parameter</u>	<u>Definition</u>
PARAM(6)	For cable problem, = L2 of series RLC at cable terminals (henries). For antenna problem, = D = antenna diameter for dipoles or monopoles (millimeters). = R = wire radius for loop antennas (meters). = A = missile radius for missile problem (meters). For cw problem, = RES = antenna resistance (ohms).
PARAM(7)	For cable problem, = C2 of series RLC at cable terminals (farads). For antenna problem, = X = H*XIN (H = missile length) representing relative position between missile tail and missile nose for current calculations (XIN = decimal number between 0. and 1.). = X = HP*XIN (HP = missile plume length) representing relative position between plume tip and missile tail for current calculations (XIN = decimal number between -1. and 0.). = LL = 2000 for system antennas AS1852 and AS1853.
PARAM(8)	For cable problem, = L = cable length (meters). For antenna problem, = HP = plume length for missile problem (meters). = ZO1 = 50 for system antennas.
PARAM(9)	For cable problem, = X = value between 0. and 1. representing fractional distance along cable for computing response. For antenna problem, = R1 of series RLC termination on cable connected to antenna for system antennas (ohms). = SIGMA = plume conductivity for missile problems. = 1.E7 (automatically) if plume length = 0.
PARAM(10)	For cable problem, = H = height of cable aboveground (meters). For antenna problem, = HG = height of antenna terminal aboveground for system, loop, monopole, and dipole antennas (meters). = HG = height of missile aboveground for missile problem (meters). For cw problem, = HG = height of test point aboveground (if antenna resistance is greater than zero) (meters). For aperture problem, = HG = height of center of aperture aboveground (meters).
PARAM(11)	For cable problem, = D = conductor diameter (meters). For antenna problem, = L1 of series RLC termination on cable connected to antenna for system antennas (henries). = ALPHA = damping constant for missile problems.
PARAM(12)	For cable problem, = S = separation distance between cables for two-conductor cable (meters). For antenna problem, = RP1 = inner plume radius for missile problem (meters). = C1 of series RLC termination on cable connected to antenna for system antennas (farads).

<u>Parameter</u>	<u>Definition</u>
PARAM(13)	For antenna problem, = outer plume radius for missile problem (meters). For frequency plot, = multiple of frequency increment (DF).
PARAM(14)	For frequency plot, = maximum frequency for response plot (hertz).
PARAM(15)	For frequency plot, = maximum frequency for field plot (hertz).
PARAM(16)	For frequency plot, = maximum frequency for impulse plot (hertz).
PARAM(17)	For frequency plot, = maximum frequency for impedance plot (hertz).
PARAM(18)	For time-domain output, = maximum time for transient output (hertz).
PARAM(19)	For time-domain output, = maximum time for field plot (hertz).
PARAM(20)	For time-domain output, = maximum time for impulse plot (hertz).

4.6 Definitions of Field Parameters (FPAR) 1 to 18

<u>Parameter</u>	<u>Definition</u>
FPAR (1)	For function-described field, = peak amplitude (volts/meter) = YMAX. For simulator field, = YMAX = peak free field at 50 m. For surface field, = YMAX.
FPAR (2)	For Gaussian field, = WIDTH = pulse width (nanoseconds). For two-exponential field, = ALPHA = one of two decay constants (per second). For sine-function field, = OMEGA = $(2\pi)/\text{PERIOD} \times 1.E9$ (PERIOD in nanoseconds). For four-exponential field, = ALPHA = one of four decay constants. For square-wave field, = WIDTH = pulse width (nanoseconds). For surface field, = ALPHA.
FPAR (3)	For two-exponential field, = BETA = one of two decay constants (per second). For sine-function field, = ALPHA = $1.E9/e\text{-folding time}$ (e-folding time in nanoseconds). For four-exponential field, = BETA = one of four decay constants. For surface field, = BETA.
FPAR (4)	For four-exponential and surface field, = GAMMA = one of four decay constants.
FPAR (5)	For four-exponential and surface field, = ETA = one of four decay constants.
FPAR (6)	For four-exponential and surface field, = A1 = one of the three "weighting" constants.
FPAR (7)	For four-exponential and surface field, = A2 = one of three "weighting" constants.

LITERATURE CITED

- (1) OS/VS2 TSO Command Language Reference, IBM Technical News Letter GC28-0646-3 (July 1976).
- (2) 6000 Series INTERCOM 3 Reference Manual, Control Data Corp. Publication 60252800, Rev. B (January 1972).
- (3) J. W. Cooley and J. W. Tukey, An Algorithm for the Machine Calculation of Complex Fourier Series, *Mathematics of Computation*, 19 (April 1965).
- (4) D. G. Dudley, Numerical Inversion of the Fourier Transform, A Combination Trapezoidal and Filon Technique, Lawrence Livermore Laboratories, Livermore, CA, UCRL-51878 (1975).
- (5) T. V. Noon, Enhanced Plotting Software for Use with the Houston Instrument COMPLOT Plotter, Harry Diamond Laboratories HDL-TM-75-32 (December 1975).
- (6) Egon Marx, Printer Version of Plots Made by an Incremental Plotter, Harry Diamond Laboratories HDL-TM-75-33 (December 1975).

APPENDIX A.—PROCEDURES FOR COMPUTER CODE TEMPO

APPENDIX A

CONTENTS

	<u>Page</u>
A-1 PROCEDURE TEMPO.....	25
A-2 PROCEDURE IO.....	26
A-3 PROCEDURE IO1.....	27
A-4 PROCEDURE IO2.....	27
A-5 PROCEDURE FRQ.....	28
A-6 PROCEDURE EFIELD.....	29
A-7 PROCEDURE INVERT.....	30
A-8 PROCEDURE CONVOL.....	31
A-9 PROCEDURE OUT.....	32

A-1. PROCEDURE TEMPO

Procedure TEMPO (listing A-1) can be used through the time sharing option (TSO) to execute interactive programs INPUT and DRIVE. After procedure TEMPO is completed, the new batch job can be submitted to the job stream by specifying a SUBMIT JOB command. The various data sets such as IO, CW, and JOB can be examined and altered by using the TSO EDIT command.

Listing A-1. Procedure TEMPO

```
00010 PROC 0
00020 CONTROL NOMSG
00030 FREE FILE(FT01F001,FT02F001,FT03F001,FT04F001,FT05F001,FT07F001)
00040 CONTROL MSG
00050 ALLOCATE DS NAME(*) FILE(FT01F001)
00060 ALLOCATE DS NAME(*) FILE(FT02F001)
00065 ALLOCATE DS NAME(IO) FILE(FT03F001)
00070 ALLOCATE DS NAME(JOB.CNTL) FILE(FT04F001)
00080 ALLOCATE DS NAME(CWDAT) FILE(FT05F001)
00090 ALLOCATE SYSOUT(B) FILE(FT07F001)
00100 FORTGO (INPT)
00110 FORTGO (DRIVE)
00120 CONTROL NOMSG
00130 FREE FILE(FT01F001,FT02F001,FT03F001,FT04F001,FT05F001,FT07F001)
00140 CONTROL MSG
END OF DATA
```

APPENDIX A

A-2. PROCEDURE IO

Procedure IO (listing A-2) is used the first time that the IO parameters are to be read from cards. At the same time, all temporary data sets to be used in a TFMPO batch job are defined.

Listing A-2 Procedure IO

```
//IOH      PREC
//* TOM HARRIS, 303-599-1745, 1 JULY 1980    , INDEFINITE
//* INITIATES INPUT AND DATA FILES
//*
//* THIS PROCEDURE READS IN 10 DATA CARDS USED TO DESCRIBE THE PROBLEM
//* TO BE EXECUTED BY TEMP0.  THIS INCLUDES DT,TOFLAG(1), FLAG(1),
//* PARAM(1), AND FPAR(1)
//*
//COPY EXEC PGM=IEHGENER
//SYSIN DD DUMMY
//SYSPRINT DD DUMMY
//SYSUT2 DD DSN=EE10,DISP=(NEW,PASS),UNIT=SYSDA,
//      SPACE=(TRK,(1,1)),
//      DCB=(RECFM=FB,LRECL=80,BLKSIZE=800)
//FT03F001 DD DSN=LLFIMP,DISP=(NEW,PASS),
//      UNIT=V10,SPACE=(TRK,(1,1)),
//      DCB=(RECFM=VS,BLKSIZE=4096)
//FT04F001 DD DSN=LEIMPLS,DISP=(NEW,PASS),
//      UNIT=V10,SPACE=(TRK,(1,1)),
//      DCB=(RECFM=VS,BLKSIZE=4096)
//FT05F001 DD DSN=EEPRINT,DISP=(NEW,PASS),
//      UNIT=V10,SPACE=(TRK,(1,1)),
//      DCB=(RECFM=VS,BLKSIZE=4096)
//FT06F001 DD DSN=EEPRINT,DISP=(NEW,PASS),
//      UNIT=V10,SPACE=(TRK,(9,9)),
//      DCB=(RECFM=FA,LRECL=133,BLKSIZE=133)
//FT07F001 DD DSN=EEPUNDATA,DISP=(NEW,PASS),
//      UNIT=V10,SPACE=(TRK,(1,1)),
//      DCB=(RECFM=FB,LRECL=80,BLKSIZE=800)
//FT08F001 DD DSN=EEFFIELD,DISP=(NEW,PASS),
//      UNIT=V10,SPACE=(TRK,(1,1)),
//      DCB=(RECFM=VS,BLKSIZE=4096)
//FT09F001 DD DSN=EEFP00D,DISP=(NEW,PASS),
//      UNIT=V10,SPACE=(TRK,(1,1)),
//      DCB=(RECFM=VS,BLKSIZE=4096)
//FT10F001 DD DSN=EERESP,DISP=(NEW,PASS),
//      UNIT=V10,SPACE=(TRK,(1,1)),
//      DCB=(RECFM=VS,BLKSIZE=4096)
//FT11F001 DD DSN=EEZA,DISP=(NEW,PASS),
//      UNIT=V10,SPACE=(TRK,(1,1)),
//      DCB=(RECFM=VS,BLKSIZE=4096)
//FT20F001 DD DSN=EENLIN,DISP=(NEW,PASS),
//      UNIT=V10,SPACE=(TRK,(9,9)),
//      DCB=(RECFM=VS,BLKSIZE=4096)
```

A-3. PROCEDURE IO1

Procedure IO1 (listing A-3) reads cards into a specified temporary data set. The default value for the temporary data set is IO, since this procedure is normally used to read a new set of parameters into the temporary data set IO.

Listing A-3. Procedure IO1

```
//IO1 PROC FILE='E1IO',OUT=X
//*   W. J. STARK, 664-6234, 17 AUG 77, INDEFINITE
//* READS IO DATA
//IO1 EXEC PGM=IEBGENER
//SYSIN DD DUMMY
//SYSPRINT DD DUMMY
//SYSUT2 DD DSN=FILE,DISP=(OLD,PASS)
//COPY EXEC PGM=IEBGENER,COND=EVEN
//SYSIN DD DUMMY
//SYSPRINT DD DUMMY
//SYSJT1 DD DSN=FILE,DISP=(OLD,PASS)
//SYSJT2 DD SYSOUT=EOUT
```

A-4. PROCEDURE IO2

Procedure IO2 (listing A-4) copies a short term or permanent data set into a specified temporary data set. The name of the input data set must be specified on the EXEC statement. The default value for the temporary data set is FIMP, since this procedure is normally used to copy continuous wave (cw) data into the temporary data set FIMP.

Listing A-4. Procedure IO2

```
//IO2 PROC IN=,OUT='E1FIMP'
//*   W. J. STARK, 664-6234, 2 APR 77, INDEFINITE
//* COPIES FILES
//COPY EXEC PGM=IEBGENER
//SYSIN DD DUMMY
//SYSPRINT DD DUMMY
//SYSJT1 DD DSN=IN,DISP=(OLD,KEEP)
//SYSJT2 DD DSN=OUT,DISP=(OLD,PASS)
// EXEC PGM=IEBGENER,COND=EVEN
//SYSIN DD DUMMY
//SYSPRINT DD DUMMY
//SYSUT1 DD DSN=OUT,DISP=(OLD,PASS)
//SYSUT2 DD SYSOUT=A
```

APPENDIX A

A-5. PROCEDURE FRQ

Procedure FRQ (listing A-5) loads and executes program FRQ with the appropriate subroutine. The appropriate FAMP subroutine must be specified on the EXEC statement. Otherwise, the default value of FAMP 1234 is used. If more than one frequency spectrum is to be computed, then FDISP = MOD must be specified on the EXEC statement.

Listing A-5 Procedure FRQ

```
//FREQH PRG=C FAMP=FAMP1234,FDISP=ULD,ZDISP=ULD
//# TOM HARRIS, 303-599-1745, 1 JULY 1980 , INDEFINITE
//# COMPUTES FAMP FILES
//LKED EXEC PGM=IEWL,REGION=250K,PARM="NOMAP,LIST,NUXREF,LET"
//#
//# THIS PROCEDURE EXECUTES THE FREQUENCY IMPULSE RESPONSE MAINLINE
//# PROGRAM. THE PROCEDURE CARD MUST HAVE FAMP=FAMP SUBROUTINE TO BE
//# EXECUTED.
//#
//SYSPRINT DL DUMMY
//SYSLIB DD DSN=HK3014.TEMPD4*,DISP=SHR
//          DD DSN=SYS1.FORTLIB,DISP=SHR
//          DD DSN=SYS1.PAGLOAD,DISP=SHR
//SYSJT1 DD UNIT=SYSDA,SPACE=(1C24,(200,20))
//SYSLMOD DD DSN=EEGOSET(MAIN),UNIT=SYSDA,DISP=(,PASS),
//          SPACE=(TRK,(10,10,2))
//SYSLIN DD DSN=HK3014.LKEDIN4(,FAMP=),DISP=SHR
//FREQ EXEC PGM=*.LKED.SYSLMOD,COND=(B,LT,LKED)
//FT02F001 DD DSN=EE11,DISP=(ULD,PASS)
//FT03F001 DD DSN=EEF1MP,DISP=(LFDISP,PASS)
//FT06F001 DD DSN=EEPRINT,DISP=(MOD,PASS)
//FT08F001 DD DSN=EEFILELU,DISP=(OLJ,PASS)
//FT09F001 DD DSN=EEFPROM,DISP=(OLD,PASS)
//FT11F001 DD DSN=EEZA,DISP=(EZDISP,PASS)
//FT20F001 DD DSN=EENLIN,DISP=(ULD,PASS)
//DD1 DD DSN=EEGOSET,DISP=(OLD,DELETE)
```

A-6. PROCEDURE EFIELD

Procedure EFIELD (listing A-6) loads and executes programs EFIELD and EFIELD1. If more than one field is to be computed, FRQ = MOD or TIM = MOD must be specified on the EXEC statement, depending on whether the field computation is in the frequency domain or the time domain.

Listing A-6. Procedure EFIELD

```

//EFIELD0H FRQ=OLD,TIM=OLD
//* T04 HARRIS,303-599-1745, 1 JULY 1980 , INDEFINITE
//* COMPUTES EFIELD
//*
//* THIS PROCEDURE EXECUTES THE EFIELD MAINLINE PROGRAM.
//*
//LKED EXEC PGM=IEWL,REGION=250K,PARM="NOMAP,LIST,NUXREF,LET"
//SYSPRINT DD DUMMY
//SYSLIB DD DSN=HK3014.TEMPC4,DISP=SHR
//          DD DSN=SYS1.FURTL1B,DISP=SHR
//          DD DSN=SYS1.PAGLUD0,DISP=SHR
//SYSJT1 DD UNIT=SYSDA,SPACE=(124,(20,20))
//SYSLMOD DD DSN=ELGUSER(MAIN),UNIT=SYSDA,DISP=(,PASS),
//          SPACE=(TRK,(10,10,2))
//SYSLIN DD DSN=HK3014.LKEDIN4(EFIELD),DISP=SHR
//EFLD EXEC PGM=*.LKED,SYSLMOD,COND=(B,LT,LKED)
//FT02F001 DD DSN=EE10,DISP=(OLD,PASS)
//FT03F001 DD DSN=EEFIMP,DISP=(LLC,PASS)
//FT05F001 DD DSN=ELFIELD,DISP=(ETIM,PASS)
//FT06F001 DD DSN=ELPRINT,DISP=(M0D,PASS)
//FT08F001 DD DSN=ELFFIELD,DISP=(EFRG,PASS)
//DD1 DD DSN=ELGUSER,DISP=(OLD,DELETE)

```

APPENDIX A

A-7. PROCEDURE INVERT

Procedure INVERT (listing A-7) loads and executes program INVERT and the appropriate subroutine. The default value for this subroutine is FFT1. Otherwise, FOURIER = LFILON must be specified on the EXEC statement. If the impulse response, the field, or the transient response is to be computed more than once, then IDISP, FDISP, or RDISP, respectively, must be set equal to MOD on the EXEC statement.

Listing A-7. Procedure INVERT

```
//INVERTH PROC IDISP=OLD,FDISP=OLD,RDISP=OLD,FOURIER=FFT1
//* TOM HARRIS, 303-599-1745, 1 JULY 1980 , INDEFINITE
//* COMPUTES FFT
//*
//* THIS PROCEDURE EXECUTES THE FOURIER TRANSFORM MAINLINE PROGRAM.
//* AS OF 1 JULY, 1980, THIS COMPUTES AN INVERSE FOURIER TRANSFORM,
//* FREQUENCY TO TIME DOMAIN, AND IT IS EXPECTED TO COMPUTE A FORWARD
//* FOURIER TRANSFORM TIME TO FREQUENCY DOMAIN, IN THE NEAR FUTURE.
//*
//LKED EXEC PGM=IEWL,REGION=250K,PARM='NOMAP,LIST,NUXREF,LET'
//SYSPRINT DD DUM4Y
//SYSLIB DD DSN='HK3014.TEMPO4',DISP=SHR
//          DD DSN=SYS1.FURTLIB,DISP=SHR
//SYSUT1 DD UNIT=SYSDA,SPACE=(1,24,(210,20))
//SYSLMOD DD DSN=EEGOSET(MAIN),UNIT=SYSDA,DISP=6,PASS),
//          SPACE=(TRK,(10,10,2))
//SYSLIN DD DSN=HK3014.LKEDIN4(FOURIER),DISP=SHR
//FOUR EXEC PGM=*.LKED.SYSLMOD,COND=(B,LT,LKED)
//FT02F001 DD DSN=EEIO,DISP=(OLD,PASS)
//FT03F001 DD DSN=EEFIMP,DISP=(OLD,PASS)
//FT04F001 DD DSN=EEIMPLS,DISP=(EIDISP,PASS)
//FT05F001 DD DSN=EEFIELD,DISP=(EFDISP,PASS)
//FT06F001 DD DSN=EEPRINT,DISP=(MOD,PASS)
//FT08F001 DD DSN=EEFFIELD,DISP=(LD,PASS)
//FT09F001 DD DSN=EEFPROM,DISP=(OLD,PASS)
//FT10F001 DD DSN=EERESP,DISP=(ERDISP,PASS)
//DD1 DD DSN=EEGOSET,DISP=(OLD,DELETE)
```

A-8. PROCEDURE CONVOL

Procedure CONVOL (listing A-8) loads and executes program CONVOL. If more than one convolution is to be performed, then FRQ = MOD or TIM = MOD must be specified on the EXEC statement, depending on whether the convolution is in the frequency domain or the time domain.

Listing A-8. Procedure CONVOL

```

//CONVOLH  PKJC TIM=L0D,FRQ=ULD
//* TDM HARRIS,303-599-1745, 1 JULY 1980 , INDEFINITE
//* COMPUTES CONVOLUTION
//*
//* THIS PROCEDURE EXECUTES THE CONVOLUTION MAINLINE PROGRAM.
//* IT COMPUTES EITHER A TIME DOMAIN CONVOLUTION OF THE IMPULSE RESPONSE
//* AND EFIELD DRIVE, OR A FREQUENCY DOMAIN PRODUCT OF THE FREQUENCY
//* DOMAIN RESPONSE AND FREQUENCY DOMAIN EFIELD DRIVE.
//*
//LKED EXEC  PGM=IEWL,REGION=250K,PARM='NDMAP,LIST,NUXREF,LET'
//SYSPRINT DD DUMMY
//SYSLIB  DD DSN='HK3014.TEMP04',DISP=SHR
//          DD DSN=SYS1.FORTLIB,DISP=SHR
//SYSUT1  DD UNIT=SYSDA,SPACE=(1(24,1200,20))
//SYSLMD  DD DSN=EEGOSET(MAIN),UNIT=SYSDA,DISP=(,PASS),
//          SPACE=(TRK,(10,10,2))
//SYSLIN  DD DSN=HK3014.LKFDTN4((CONVOL),DISP=SHR
//CNV EXEC PGM=*.LKED,SYSLMD,COND=(8,LT,LKED)
//FT02F001 DD DSN=EE10,DISP=(OLD,PASS)
//FT03F001 DD DSN=EEFIMP,DISP=(OLD,PASS)
//FT04F001 DD DSN=EEIMPLS,DISP=(OLD,PASS)
//FT05F001 DD DSN=EEFIELD,DISP=(OLD,PASS)
//FT06F001 DD DSN=EEPRINT,DISP=(HLD,PASS)
//FT08F001 DD DSN=EEFFFILE,DISP=(OLD,PASS)
//FT09F001 DD DSN=EEFPROD,DISP=(ERASE,PASS)
//FT10F001 DD DSN=EERESP,DISP=(ETIM,PASS)
//DD1 DD DSN=EEGOSET,DISP=(OLD,DELETE)

```

APPENDIX A

A-9. PROCEDURE OUT

Procedure OUT (listing A-9) loads and executes program OUT. The default value of OFFPLOT = 'HKZ001 OFFPLOT' allows the user to write output to the bed plotter on magnetic tape for subsequent off-line plotting. The substitutable parameter OFFPLOT must be set equal to SYS1 DUMMYLIB for on-line plotting. The default value of HLDPLT = YES allows the output to the plotter to be placed in hold so that the operator can mount a magnetic tape for the off-line plot option. Otherwise, the user must specify HLDPLT = NO on the EXEC statement. Substitutable parameters SYST and HLDPRT are used when a job is submitted through TSO and it is desired to recover the output at the TSO terminal such as a plot on the teletypewriter. In that case, the user must set SYST = Z and HLDPRT = YES. The output can then be recovered at the TSO terminal by issuing the OUTPUT (JOBID) command.

Listing A-9. Procedure OUT

```

//DUTH      PROC OFFPLOT='HK3014.OFFPLOT',SYST=A,HLDPLT=YES,HLDPRT=NO,
//          DIS=PASS,PUN=B
//* TOM HARRIS, 303-599-1745, 1 JULY 1980 , INDEFINITE
//* OUTPUT ROUTINE
//*
//*      THIS PROCEDURE PLOTS THE OUTPUT RESULTS FROM TEMPO AS CONTROLLED
//*      BY THE IOFLAGS IN THE IO DATA DECK
//*
//LKED EXEC  PGM=IEWL,REGION=250K,PARM="NOMAP,LIST,NOXREF,LET"
//SYSPRINT DD DUMMY
//SYSLIB  DD DSN=EUFPLOT,DISP=SHR
//          DD DSN='HK3010.ANAPAC',DISP=SHR
//          DD DSN=SYS1.FURTLIB,DISP=SHR
//          DD DSN=SYS1.PAGLOAD,DISP=SHR
//          DD USN='HK3014.TEMPG4',DISP=SHR
//SYSJT1  DD UNIT=SYSDA,SPACE=(1024,(200,20))
//SYSLMD  DD DSN=ELGUSER(MAIN),UNIT=SYSDA,DISP=(,PASS),
//          SPACE=(TRK,(10,10,2))
//SYSLIN  DD DSN=HK3014.LKEDIN4(LUT),DISP=SHR
//DUT      EXEC PGM=*.LKED,SYSLMD,COND=(B,LT,LKED)
//FT01F001 DD UNIT=V10,DISP=(,PASS),SPACE=(CYL,(1,1))
//FT02F001 DD DSN=EL1U,DISP=(OLD,DELETE)
//FT03F001 DD DSN=EEFIMM,DISP=(OLD,DELETE)
//FT04F001 DD DSN=EE1MPLS,DISP=(OLD,DELETE)
//FT05F001 DD DSN=EEFIELD,DISP=(OLD,DELETE)
//FT06F001 DD DSN=EEPRINT,DISP=(OLD,PASS)
//FT08F001 DD USN=EEFFIELD,DISP=(1,DELETE)
//FT09F001 DD DSN=EEFPROM,DISP=(OLD,LDIS)
//FT10F001 DD DSN=EERESP,DISP=(OLD,LDIS)
//FT11F001 DD DSN=EL2A,DISP=(OLD,LDIS)
//FT12F001 DD UNIT=V10,DISP=(,PASS),SPACE=(CYL,(1,1))
//FT20F001 DD DSN=LENLIN,DISP=(OLD,DELETE)
//          EXEC PGM=IEBGENER,COND=EVEN
//SYSIN DD DUMMY
//SYSPRINT DD DUMMY
//SYSJT1 DD DSN=EEPRINT,DISP=(OLD,DELETE)
//SYSUT2 DD SYSOUT=ESYST,HOLD=EHLDPLT
//DD1  DD DSN=ELGUSER,DISP=(OLD,DELETE)
//      EXEC PGM=IEBGENER,COND=EVEN
//SYSIN DD DUMMY
//SYSPRINT DD DUMMY
//SYSJT1 DD DSN=EEPUNDATA,DISP=(OLD,DELETE)
//SYSUT2 DD SYSOUT=EPUN,HOLD=EHLDPLT

```

DISTRIBUTION

ADMINISTRATOR
DEFENSE TECHNICAL INFORMATION CENTER
ATTN DTIC-DDA (12 COPIES)
CAMERON STATION, BUILDING 5
ALEXANDRIA, VA 22314

COMMANDER
US ARMY RSCH & STD GP (EUR)
ATTN CHIEF, PHYSICS & MATH BRANCH
FPO NEW YORK 09510

COMMANDER
US ARMY MISSILE & MUNITIONS
CENTER & SCHOOL
ATTN ATSK-CTD-F
REDSTONE ARSENAL, AL 35809

DIRECTOR
US ARMY MATERIEL SYSTEMS ANALYSIS
ACTIVITY
ATTN DRXSY-MP
ATTN DRXSY-PO
ABERDEEN PROVING GR ND, MD 21005

DIRECTOR
US ARMY BALLISTIC RESEARCH LABORATORY
ATTN DRDAR-TSB-S (STINFO)
ATTN DRXBR-AM, W. VANANTWERP
ATTN DRSTE-EL
ATTN DRDAR-BLE
ABERDEEN PROVING GROUND, MD 21005

US ARMY ELECTRONICS TECHNOLOGY
AND DEVICES LABORATORY
ATTN DELET-DD
FORT MONMOUTH, NJ 07703

HQ, USAP/SAMI
WASHINGTON, DC 20330

TELEDYNE BROWN ENGINEERING
CUMMINGS RESEARCH PARK
ATTN DR. MELVIN L. PRICE, MS-44
HUNTSVILLE, AL 35807

DIRECTOR
ARMED FORCES RADIobiology
RESEARCH INSTITUTE
DEFENSE NUCLEAR AGENCY
NATIONAL NAVAL MEDICAL CENTER
ATTN RESEARCH PROGRAM
COORDINATING OFFICER
BETHESDA, MD 20014

ASSISTANT TO THE SECRETARY OF DEFENSE
ATOMIC ENERGY
ATTN EXECUTIVE ASSISTANT
WASHINGTON, DC 20301

DIRECTOR
DEFENSE ADVANCED RSCH PROJ AGENCY
ARCHITECT BUILDING
1400 WILSON BLVD
ATTN TIO
ARLINGTON, VA 22209

FEDERAL EMERGENCY MANAGEMENT AGENCY
ATTN JAMES W. KERR
MITIGATION & RESEARCH
WASHINGTON, DC 20472

DIRECTOR
DEFENSE COMMUNICATIONS AGENCY
ATTN CODE C312
ATTN CODE C313
WASHINGTON, DC 20305

DEFENSE COMMUNICATIONS ENGINEERING
CENTER
1860 WIEHLE AVENUE
ATTN CODE R720, C. STANSBERRY
ATTN CODE R123, RECH LIB
ATTN CODE R400
RESTON, VA 22090

DIRECTOR
DEFENSE INTELLIGENCE AGENCY
ATTN RDS-3A
ATTN RDS-3A4, POMPONIO PLAZA
WASHINGTON, DC 20301

DIRECTOR
DEFENSE NUCLEAR AGENCY
ATTN DDST, E. E. CONRAD, DEP DIR
SCI & TECH
ATTN RAEV, ELECTRONICS VULNERABILITY
DIV
ATTN TITL, TECHNICAL LIBRARY DIV
ATTN RAEE, EMP EFFECTS DIV
WASHINGTON, DC 20305

COMMANDER
FIELD COMMAND
DEFENSE NUCLEAR AGENCY
ATTN FCPR
ATTN FCSPM, J. SMITH
ATTN FCLMC
KIRTLAND AFB, NM 87115

DIRECTOR
INTERSERVICE NUCLEAR WEAPONS SCHOOL
ATTN TTV
KIRTLAND AFB, NM 87115

JOINT CHIEFS OF STAFF
ATTN J-3
WASHINGTON, DC 20301

DIRECTOR
JOINT STRATEGIC TARGET PLANNING
STAFF, JCS
ATTN JSAS
ATTN JPST
ATTN NRI-STINFO LIBRARY
OFFUTT AFB
OMAHA, NM 68113

CHIEF
LIVERMORE DIVISION, FIELD COMMAND DNA
LAWRENCE LIVERMORE LABORATORY
P.O. BOX 808
ATTN FCPR
LIVERMORE, CA 94550

NATIONAL COMMUNICATIONS SYSTEM
OFFICE OF THE MANAGER
DEPARTMENT OF DEFENSE

ATTN NCS-TS, CHARLES D. BODSON
WASHINGTON, DC 20305

DIRECTOR
NATIONAL SECURITY AGENCY
DEPARTMENT OF DEFENSE
ATTN R-52, O. VAN GINTEN
ATTN S232, D. VINCENT
FT GEORGE G. MEADE, MD 20755

UNDER SECRETARY OF DEF FOR RSCH &
ENGRG
DEPARTMENT OF DEFENSE
ATTN G. RARSE
ATTN S4SS (OS)
WASHINGTON, DC 20301

COMMANDER
BMD SYSTEM COMMAND
DEPARTMENT OF THE ARMY
P.O. BOX 1500
ATTN BMDSC-AOLB
HUNTSVILLE, AL 35807

COMMANDER
ERADCOM TECHNICAL SUPPORT ACTIVITY
DEPARTMENT OF THE ARMY
ATTN DRDCO-COM-ME, G. GAULE
ATTN DELSD-L, TECHNICAL LIBRARY DIV
ATTN DELCS-K, A. COHEN
ATTN DELET-IR, E. HUNTER
FT MONMOUTH, NJ 07703

COMMANDER
US ARMY ARMORE CENTER
ATTN TECHNICAL LIBRARY
FORT KNOX, KY 40121

COMMANDER
US ARMY COMM-ZIEC ENGRG INSTAL AGENCY
ATTN CCC-PRSO-S
ATTN CCC-CED-SES
FT HUACHUCA, AZ 85613

COMMANDER
US ARMY COMMUNICATIONS COMMAND
ATTN CL-OPS-PD
ATTN CC-OPS-OS
FT HUACHUCA, AZ 85613

COMMANDER
US ARMY COMMUNICATIONS COMMAND
COMBAT DEVELOPMENT DIVISION
ATTN ATSI-CD-MD
FT HUACHUCA, AZ 85613

CHIEF
US ARMY COMMUNICATIONS SYS AGENCY
ATTN CCM-RD-T, CCM-AD-SV
FT MONMOUTH, NJ 07703

PROJECT OFFICER
US ARMY COMMUNICATIONS RES
& DEV COMMAND
ATTN DRCPM-ATC
ATTN DRCPM-TDS-BSI
FT MONMOUTH, NJ 07703

DIVISION ENGINEER
US ARMY ENGINEER DIV, HUNTSVILLE
P.O. BOX 1600, WEST STATION
ATTN HNDED-SR
ATTN A. T. BOLT
HUNTSVILLE, AL 35807

US ARMY INTEL THREAT
ANALYSIS DETACHMENT
ROOM 2201, BLDG A
ARLINGTON HALL STATION
ATTN RM 2200, BLDG A
ARLINGTON, VA 22212

COMMANDER
US ARMY INTELLIGENCE & SEC CMD
ARLINGTON HALL STATION
4000 ARLINGTON BLVD
ATTN TECHNICAL LIBRARY
ATTN TECH INFO FAC
ARLINGTON, VA 22212

DISTRIBUTION (Cont'd)

COMMANDER US ARMY MISSILE COMMAND ATTN DRCM-PM-EM, WALLACE O. WAGNER ATTN DRCM-PM-EG, WILLIAM B. JOHNSON ATTN DROMI-TBD ATTN DROMI-EAA REDSTONE ARSENAL, AL 35809	COMMANDER NAVAL SURFACE WEAPONS CENTER DAHlgREN LABORATORY ATTN CODE DP-56 DAHLGREN, VA 22448	COMMANDER OGDEN ALC/MMEDDE DEPARTMENT OF THE AIR FORCE ATTN OO-ALC/MMETH, P. W. HERTEL ATTN MMEDDE, LEO KIDMAN ATTN MAJ R. BLACKBURN HILL AFB, UT 84463
COMMANDER US ARMY TEST AND EVALUATION COMMAND ATTN DRSTE-FA ABERDEEN PROVING GROUND, MD 21005	COMMANDER NAVAL WEAPONS CENTER ATTN CODE 533, TECH LDR CHINA LAKE, CA 93555	COMMANDER ROME AIR DEVELOPMENT CENTER, AFSC ATTN TSUO SKIFFISS AFB, NY 11441
COMMANDER US ARMY TRAINING AND DOCTRINE COMMAND ATTN ATODI-OP-SW FT MONROE, VA 23651	COMMANDING OFFICER NAVAL WEAPONS EVALUATION FACILITY KIRTLAND AIR FORCE BASE ATTN CODE AT-6 ALBUQUERQUE, NM 87117	COMMANDER SACRAMENTO AIR LOGISTICS CENTER DEPARTMENT OF THE AIR FORCE ATTN MMHHS, H. A. PELMAYER ATTN MMHKS, T. W. HEMER ATTN MMHSM, F. R. SPEAR MCCLELLAN AFB, CA 94577
COMMANDER WHITE SANDS MISSILE RANGE DEPARTMENT OF THE ARMY ATTN STEWS-TE-AN, J. OKUMA WHITE SANDS MISSILE RANGE, NM 88002	DIRECTOR STRATEGIC SYSTEMS PROJECT OFFICE NAVY DEPARTMENT ATTN NSP-2701, JOHN W. PITSCHERBERGER ATTN NSP-2142, RICHARD L. COLEMAN ATTN NSP-43, THOMAS L. BUR ATTN NSP-27334 ATTN NSP-2301, D. GOLD WASHINGTON, DC 20330	SAC-1 AIR FORCE SYSTEMS COMMAND POST OFFICE BOX 32400 WILLOWAY POSTAL CENTER INTELLIGENCE ATTN INC LOS ANGELES, CA 90044
OFFICER-IN-CHARGE CIVIL ENGINEERING LABORATORY NAVAL CONSTRUCTION BATTALION CENTER ATTN CODE LORA (LIBRARY) ATTN CODE LORA PORT HUENEME, CA 93041	COMMANDER AERONAUTICAL SYSTEMS DIVISION, AFSC ATTN ASD-YH-EX ATTN ENPTV WRIGHT-PATTERSON AFB, OH 45433	SAC-2 AIR FORCE SYSTEMS COMMAND MINIMAN ATTN MNHII, MAT M. BAKAN ATTN MNHII, CAPT R. L. LAWRENCE NORFOLK AFB, VA 23501
COMMANDER NAVAL ELECTRONIC SYSTEMS COMMAND ATTN PME 117-215 WASHINGTON, DC 20360	AIR FORCE TECHNICAL APPLICATIONS CENTER ATTN TPS, M. SCHNEIDER PATRIOT AFB, FL 32025	SAC-3 AIR FORCE SYSTEMS COMMAND POST OFFICE BOX 32400 WILLOWAY POSTAL CENTER ATTN YAH LOS ANGELES, CA 90044
COMMANDER NAVAL OCEAN SYSTEMS CENTER ATTN CODE 015, C. FLETCHER ATTN RESEARCH LIBRARY ATTN CODE 7240, S. W. LIGHTMAN SAN DIEGO, CA 92152	AF WEAPONS LABORATORY, AFSC ATTN NPN ATTN NT ATTN EL, CARL E. BAUM ATTN ELXT ATTN SUL ATTN TA ATTN ELA, J. P. CASTILLO ATTN ELP ATTN EIT, W. PAGE ATTN NXS KIRTLAND AFB, NM 87117	STRATEGIC AIR COMMAND XPS ATTN NM-TECH-1 LIBRARY ATTN OPI ATTN GARNET F. MATTHE ATTN XPS, MAJ BRADEN M. STEPHAN WRIGHT AFB, NY 14214
COMMANDING OFFICER NAVAL ORDNANCE STATION ATTN STANDARDIZATION DIV INDIAN HEAD, MD 20640	DIRECTOR AIR UNIVERSITY LIBRARY DEPARTMENT OF THE AIR FORCE ATTN AUL-LSE-70-250 MAXWELL AFB, AL 36112	DEPARTMENT OF ENERGY ALBUQUERQUE OPERATIONS OFFICE POB BOX 3400 ATTN TECH LIBRARY ATTN OPERATIONAL SAFETY DIV ALBUQUERQUE, NM 87119
SUPERINTENDENT (CODE 1424) NAVAL POSTGRADUATE SCHOOL ATTN CODE 1424 MONTEREY, CA 931940	HEADQUARTERS ELECTRONIC SYSTEMS DIVISION/SEA DEPARTMENT OF THE AIR FORCE ATTN YSEA HANSCOM, AFB MA 01731	UNIVERSITY OF CALIFORNIA LAWRENCE LIVERMORE LABORATORY PO BOX 8000 ATTN TECH LIBRARY ATTN L-091, P. DUNLOP ATTN L-545, D. MEEKER ATTN L-150, F. MILLER ATTN L-150, H. KRUEGER ATTN H. S. TARAYAN LIVERMORE, CA 94550
DIRECTOR NAVAL RESEARCH LABORATORY ATTN CODE 4104, EMANUEL L. BRANCATO ATTN CODE 2627, DORIS R. POLEN ATTN CODE 6623, RICHARD L. STATTER ATTN CODE 6624 WASHINGTON, DC 20375	COMMANDER FOREIGN TECHNOLOGY DIVISION, AFSC ATTN NICD LIBRARY ATTN ETDP, R. L. BALLARD WRIGHT-PATTERSON AFB, OH 45433	LOS ALAMOS SCIENTIFIC LABORATORY POB BOX 1663 ATTN WHITE W. NORT ATTN CLARENCE WENTON LOS ALAMOS, NM 87545
COMMANDER NAVAL SURFACE WEAPONS CENTER ATTN CODE WAS1R0, RM 110-108 ATTN CODE F13, EDWIN R. RATHBURN WHITE OAK, SILVER SPRING, MD 20910		

DISTRIBUTION (cont'd)

NORTHROP CORPORATION
ELECTRONIC DIVISION
2301 WEST 120TH STREET
ATTN: LEW SMITH
ATTN: RAD EFFECTS GRP
HAWTHORNE, CA 90250

PHYSICS INTERNATIONAL COMPANY
2700 MERED STREET
ATTN: DOC CON
SAN LEANDRO, CA 94577

R&D ASSOCIATES
P.O. BOX 9645
ATTN: S. CLAY ROGERS
ATTN: CHARLES MO
ATTN: RICHARD R. SCHAEFER
ATTN: DOC CON
ATTN: M. GROVER
ATTN: G. MACDONALD
ATTN: J. BOMBARDT
MARINA DEL REY, CA 90291

R&D ASSOCIATES
1401 WILSON BLVD
SUITE 500
ATTN: J. BOMBARDT
ARLINGTON, VA 22209

RAND CORPORATION
1700 MAIN STREET
ATTN: LIB-D
ATTN: J. SOLLEFREY
SANTA MONICA, CA 90406

RAYTHEON COMPANY
HARVEY ROAD
ATTN: GAJANAN H. JOSHI
BEDFORD, MA 01730

RAYTHEON COMPANY
528 BOSTON POST ROAD
ATTN: HAROLD L. FLESCHER
SUDBURY, MA 01776

RCA CORPORATION
GOVERNMENT SYSTEMS DIVISION
ASTRO ELECTRONICS
P.O. BOX 800, LAKESIDE CORNER
EAST WINDSOR TOWNSHIP
ATTN: ROGER J. BRUNKER
PRINCETON, NJ 08540

RCA CORPORATION
DAVID SARNOFF RESEARCH CENTER
P.O. BOX 410
ATTN: SECURITY DEPT, L. MINICH
PRINCETON, NJ 08540

RCA CORPORATION
TAMKEN COMPLEX
FRONT & NUMBER STREETS
ATTN: ALICE WHITEHEAD
ATTN: R. W. ROSTROM
TAMKEN, NJ 08042

ROCKWELL INTERNATIONAL CORP.
P.O. BOX 3111
ATTN: M. J. WHITE
ATTN: T. G. MINOR
ATTN: M. J. MICHIE
ATTN: M. J. MICHIE, 111-100
ANAHEIM, CA 92801

ROCKWELL INTERNATIONAL CORP.
SPACE DIVISION
12214 SOUTH LAKWOOD BOULEVARD
ATTN: B. E. WHITE
DOWNNEY, CA 90241

ROCKWELL INTERNATIONAL CORPORATION
815 LAFHAM STREET
ATTN: B-1, DIV TIC (RAOR)
EL SEGUNDO, CA 90245

ROCKWELL INTERNATIONAL CORPORATION
P.O. BOX 369
ATTN: F. A. SHAW
CLEARFIELD, UT 84015

SANDERS ASSOCIATES, INC.
95 CANAL STREET
ATTN: 1-6270, R. G. DESPATRY, SR P.E.
NASHUA, NH 03060

SCIENCE APPLICATIONS, INC.
P.O. BOX 277
ATTN: FREDERICK M. TEISCHER
BERKELEY, CA 94701

SCIENCE APPLICATIONS, INC.
P.O. BOX 2351
ATTN: R. PARKINSON
LA JOLLA, CA 92038

SCIENCE APPLICATIONS, INC.
HUNTSVILLE DIVISION
2103 W. CLINTON AVENUE
SUITE 700

ATTN: NOEL R. BYRN
HUNTSVILLE, AL 35815

SCIENCE APPLICATIONS, INC.
8400 WESTPARK DRIVE
ATTN: WILLIAM L. CHADSEY
MCLEAN, VA 22101

SINGER COMPANY
1150 MC BRIDE AVENUE
ATTN: TECH INFO CTR
LITTLE FALLS, NJ 07424

SPERRY RAND CORPORATION
SPERRY MICROWAVE ELECTRONICS
P.O. BOX 4849
ATTN: MARGARET CORT
CLEARWATER, FL 33518

SPERRY RAND CORPORATION
SPERRY DIVISION
MARTIS AVENUE
ATTN: TECH LIB
GREAT NECK, NY 11020

SPERRY RAND CORPORATION
SPERRY FLIGHT SYSTEMS
P.O. BOX 21111
ATTN: D. ANDREW SCHOW
PHOENIX, AZ 85064

SPERRY CORPORATION
P.O. BOX 9
ATTN: JOHN R. DUDUM
ATTN: ROGER J. LITTLE
BEDFORD, MA 01730

SRI INTERNATIONAL
333 RAVENSWOOD AVENUE
ATTN: ARTHUR LEE WHITSON
MENLO PARK, CA 94025

SYSTEMS, SCIENCE AND SOFTWARE, INC.
P.O. BOX 1620
ATTN: ANDREW R. WILSON
LA JOLLA, CA 92038

TEXAS INSTRUMENTS, INC.
P.O. BOX 4015
ATTN: TECH LIB
ATTN: RONALD J. MANUS
DALLAS, TX 75246

TRW DEFENSE & SPACE SYS GROUP
ONE SPATIAL PARK
ATTN: G. E. ADAMS
ATTN: R. K. PLEBISH
ATTN: L. R. MAGNUSIA
ATTN: H. H. HOLLOWAY
ATTN: W. GARNER
REDONDO BEACH, CA 90278

TEXAS TECH UNIVERSITY
P.O. BOX 5404, NORTH TEXAS STATION
ATTN: DAVID L. SIMPSON
LUBBOCK, TX 79417

UNITED TECHNOLOGIES CORP.
HAMILTON STANDARD DIVISION
READILY INTERNATIONAL AIRPORT
ATTN: CHIEF ELEC DESIGN
WINDSOR LOCKS, CT 06094

WESTINGHOUSE ELECTRIC CORP. EAST
ADVANCED ENERGY SYSTEMS DIV
P.O. BOX 10064
ATTN: TECH LIB
PITTSBURGH, PA 15236

US ARMY ELECTRONICS RESEARCH
& DEVELOPMENT COMMAND
ATTN: TECHNICAL DIRECTOR, DRDEL-ET

HARRY DIAMOND LABORATORIES
ATTN: COMINT/TSO DIVISION DIRECTOR
ATTN: READER COPY, 21200
ATTN: HSI LIBRARY, 21111 (3 COPIES)
ATTN: HSI LIBRARY, 21111 (WOODBRIDGE)
ATTN: PROFESSIONAL REPORTS BRANCH, 21200
ATTN: CHAIRMAN, EDITORIAL COMMITTEE
ATTN: LEGAL OFFICE, 21200
ATTN: CHIEF, 21000
ATTN: CHIEF, 21100
ATTN: CHIEF, 21200
ATTN: CHIEF, 21300 (3 COPIES)
ATTN: CHIEF, 21400
ATTN: CHIEF, 21500
ATTN: CHIEF, 22000
ATTN: CHIEF, 22100
ATTN: CHIEF, 22300
ATTN: CHIEF, 22800
ATTN: CHIEF, 22900
ATTN: CHIEF, 23240
ATTN: WIMENITZ, P.O. BOX 23240
ATTN: HUTCHINS, P.O. BOX 23240
ATTN: CHASE, P.O. BOX 23240
ATTN: VALLING, P.O. BOX 23240
ATTN: PEMERITAS, P.O. BOX 23240
ATTN: LEPPNER, P.O. BOX 23240
ATTN: REYER, P.O. BOX 23240

